

DUTCH DOOR

EXTERIOR DOOR: CUT $\frac{3}{8}$ IN OUT OF DOOR;
APPLY SWEEP IN GAP BETWEEN TOP AND BOTTOM.

STANDARD BORE FOR STANDARD SPLIT DOOR:
3" ON CENTER FROM EDGE OF CUT IN DOOR. (TOP AND
BOTTOM.) FOR DUTCH DOOR SHELF WITH CORBELS, BORE
IN LOWER HALF OF DOOR MUST BE DOWN FARTHER, OR
CUSTOMER WILL NOT BE ABLE TO USE LEVER STYLE DOOR
LATCH.

CORBEL PLACEMENT: A OUT SIDE OF CORBEL
WITH STYLE/RAIL JOINT.

PLACE CENTER 2 HINGES 4 IN. FROM SIDE OF
HINGE TO EDGE OF CUT IN DOOR.